



# User Guide

Unmanaged Pro Switch

TL-SG105E/TL-SG108E/TL-SG116E

1910012413 REV4.0.1

May 2018

# CONTENTS

## About This Guide

Intended Readers .....	1
Conventions.....	1
More Information .....	1

## Introduction

Product Overview .....	4
Appearance Description .....	5
Front Panel .....	5
Rear Panel.....	6
Logging Into the Switch.....	7

## Managing System

System .....	10
Overview.....	10
Supported Features .....	10
Configuring System Info .....	11
Viewing the System Information .....	11
Specifying the Device Description .....	11
Configuring IP.....	12
Configuring User Account.....	14
Backing up and Restoring the Switch .....	15
Saving the Current Configuration.....	15
Restoring to the Previous Configuration.....	16
Rebooting the Switch.....	18
Reseting the Switch .....	19
Upgrading the Firmware.....	20
Appendix: Default Parameters.....	25

## Switching

Switching.....	27
Overview.....	27
Supported Features .....	27
Configuring Ports.....	29

Configuring IGMP Snooping .....	31
Configuring LAG.....	32
Configuration Examples .....	33
Example for Configuring IGMP Snooping .....	33
Network Requirements .....	33
Configuration Scheme.....	33
Configuration Steps .....	34
Example for Configuring LAG .....	35
Network Requirements .....	35
Configuration Steps .....	35
Appendix: Default Parameters.....	36

## Monitoring

Monitoring .....	38
Overview.....	38
Supported Features.....	38
Viewing Port Statistics.....	39
Configuring Port Mirror.....	40
Testing Cables .....	42
Configuring Loop Prevention.....	43
Appendix: Default Parameters.....	44

## Configuring VLAN

Overview .....	46
Configuring MTU VLAN.....	48
Configuring Port Based VLAN.....	49
Configuring 802.1Q VLAN .....	50
Configuring the VLAN .....	50
Configuring the PVID .....	51
Configuration Example for 802.1Q VLAN.....	53
Network Requirements.....	53
Configuration Scheme .....	53
Network Topology.....	54
Configuration Steps.....	55
Appendix: Default Parameters.....	58

## Configuring QoS

QoS.....	60
Overview.....	60
Supported Features.....	60
Configuring Basic QoS .....	61
Configuring QoS in Port Based Mode.....	62
Configuring QoS in 802.1P Based Mode.....	62
Configuring QoS in DSCP Based Mode.....	63
Configuring Bandwidth Control.....	64
Configuring Storm Control.....	65
Configuration Example for Basic QoS.....	67
Network Requirements.....	67
Configuration Scheme .....	67
Configuration Steps.....	68
Appendix: Default Parameters.....	69

# About This Guide

This Configuration Guide provides information for configuring the Unmanaged Pro Switch via the web interface. Read this guide carefully before operation.

You can also configure the switch using the Unmanaged Pro Configuration Utility. For more information, refer to the **Unmanaged Pro Configuration Utility User Guide**. Go to the website <https://www.tp-link.com/support>, search the model number of your switch, and you can find this guide on the product Support web page.

## Intended Readers

This Guide is intended for network managers familiar with IT concepts and network terminologies.


## Conventions

Some models featured in this guide may be unavailable in your country or region. For local sales information, visit <https://www.tp-link.com>.

When using this guide, notice that features of the switch may vary slightly depending on the model and software version you have. All screenshots, images, parameters and descriptions documented in this guide are used for demonstration only. Throughout the guide, we will take TL-SG105E as the switch to be configured for example.

The information in this document is subject to change without notice. Every effort has been made in the preparation of this document to ensure accuracy of the contents, but all statements, information and recommendations in this document do not constitute the warranty of any kind, express or implied. Users must take full responsibility for their application of any products.

In this Guide, the following conventions are used:

The symbol  stands for *Note*. Notes contain suggestions or references that help you make better use of your device.

**Menu Name > Submenu Name > Tab page** indicates the menu structure. **SYSTEM > System Info > System Summary** means the System Summary page under the System Info menu option that is located under the SYSTEM menu.

**Bold font** indicates a button, a toolbar icon, menu or menu item.

## More Information

- The latest software and documentations can be found at Download Center at <https://www.tp-link.com/support>.

- The Installation Guide (IG) can be found where you find this guide or inside the package of the switch.
- Specifications can be found on the product page at <https://www.tp-link.com>.
- A Technical Support Forum is provided for you to discuss our products at <http://forum.tp-link.com>.
- Our Technical Support contact information can be found at the Contact Technical Support page at <https://www.tp-link.com/support>.

# Part 1

## Introduction

### CHAPTERS

1. Product Overview
2. Appearance Description
3. Logging Into the Switch

# 1 Product Overview

The TL-SG105E/TL-SG108E/TL-SG116E Unmanaged Pro Switch is an ideal upgrade from an unmanaged switch, designed for Small Office and Home Office networks. The switch supports the following features:

- **Traffic monitoring:** Port mirroring, loop prevention and cable test enable the administrator to monitor traffic of the network effectively.
- **VLAN:** MTU VLAN, Port based VLAN and 802.1Q VLAN can restrict broadcast domain, enhance network security and help manage devices easily.
- **QoS:** Port based QoS, 802.1P based QoS and DSCP based QoS optimize traffic on your business network, and keep latency-sensitive traffic moving smoothly. Bandwidth control helps distribute and utilize network bandwidth reasonably. Storm control helps avoid network broadcast storm.




# 2 Appearance Description

## 2.1 Front Panel

The front panel of TL-SG105E is shown as the following figure.

Figure 2-1 Front Panel of TL-SG105E




The front panel of TL-SG108E is shown as the following figure.

Figure 2-2 Front Panel of TL-SG108E



The front panel of TL-SG116E is shown as the following figure.

Figure 2-3 Front Panel of TL-SG116E



### LEDs

LED	Indication
Power	<b>On:</b> The switch is powered on. <b>Off:</b> The switch is powered off or power supply is abnormal.
1000M (Green)	<b>On:</b> Running at 1000Mbps, but no activity. <b>Flashing:</b> Running at 1000Mbps and is transmitting or receiving data.
10/100Mbps (Yellow)	<b>On:</b> Running at 10/100Mbps, but no activity. <b>Flashing:</b> Running at 10/100Mbps and is transmitting or receiving data.


### 10/100/1000Mbps RJ45 Port

Designed to connect to the device with a bandwidth of 10Mbps, 100Mbps or 1000Mbps.

## 2.2 Rear Panel

The rear panel of TL-SG105E is shown as the following figure.

Figure 2-4 Rear Panel of TL-SG105E




The rear panel of TL-SG108E is shown as the following figure.

Figure 2-5 Rear Panel of TL-SG108E



The rear panel of TL-SG116E is shown as the following figure.

Figure 2-6 Rear Panel of TL-SG116E



### Kensington Security Slot

Secure the lock (not provided) into the security slot to prevent the device from being stolen.

### Reset

With the switch powered on, press this button for five seconds or above to reset the software setting back to factory default setting.

### DC Power Socket


Connect the female connector of the power cord here, and the male connector to the AC power outlet. Make sure the voltage of the power supply meets the requirement of the input voltage (9V/0.6A for TL-SG105E and TL-SG108E, 12V/1A for TL-SG116E).

# 3 Logging Into the Switch

To configure your switch through a web browser on your PC, follow these steps:

- 1) Connect your switch to the network and connect your PC to the switch.
- 2) Find out the IP address of the switch.
  - By default, the switch receives an IP address from a DHCP server (or a router that functions as a DHCP server) in your network. You can find out this IP address on the DHCP server.
  - If the switch cannot receive an IP address from a DHCP server, it uses the static IP address of 192.168.0.1, with a subnet mask of 255.255.255.0.
- 3) Configure IP address on your PC to make sure the switch and PC are in the same subnet.
  - If the switch uses an IP address assigned by a DHCP server, set your PC to obtain an IP address automatically from the DHCP server.
  - If the switch uses the static IP address of **192.168.0.1**, configure your PC's IP address as **192.168.0.x** ("x" ranges from 2 to 254), and subnet mask as **255.255.255.0**.
- 4) Launch a web browser on your PC. The supported web browsers include, but are not limited to, the following types:
  - IE 8.0, 9.0, 10.0, 11.0
  - Firefox 26.0, 27.0
  - Chrome 32.0, 33.0
- 5) In the address bar of the web browser, enter the IP address of the switch. Here we suppose the switch uses the static IP address **192.168.0.1**.

Figure 3-1 Entering the IP Address of the Switch in the Browser



- 6) Enter the username and password in the pop-up login window. Enter **admin** for both username and password in lower case letters.


Figure 3-2 Logging Into the Switch



The image shows the TP-Link login interface. At the top, there is a dark header with the TP-Link logo. Below the header, the text "User Name:" is followed by a text input field containing "admin". Below that, the text "Password:" is followed by a password input field with six dots. At the bottom, there are two buttons: "Login" and "Clear".

- 7) The typical web interface displays below. You can view the running status of the switch and configure the switch on this interface.

Figure 3-3 Launching the Web Interface



The image shows the TP-Link web interface for a TL-SG105E switch. The top header features the TP-Link logo and the model name "TL-SG105E". On the left, there is a navigation menu with the following items: System, Switching, Monitoring, VLAN, QoS, and Logout. The main content area displays "System Info" with a table of device details and a form to update the device description.

Device Description	TL-SG105E
MAC Address	B0.4E.26.A0.FB.87
IP Address	192.168.0.1
Subnet Mask	255.255.255.0
Default Gateway	0.0.0.0
Firmware Version	1.0.0 Build 20171127 Rel.40600
Hardware Version	TL-SG105E 4.0

Device Description:

**Note:**  
The length of device description should not be more than 32 characters.

# Part 2

## Managing System

### CHAPTERS

1. System
2. Configuring System Info
3. Configuring IP
4. Configuring User Account
5. Backing up and Restoring the Switch
6. Rebooting the Switch
7. Reseting the Switch
8. Upgrading the Firmware
9. Appendix: Default Parameters

# 1 System

## 1.1 Overview

In System module, you can view the system information and configure the system parameters and features of the switch.

## 1.2 Supported Features

### System Info

The System Info is mainly used to view the system information and configure the device description.

### IP Setting

Each device in the network possesses a unique IP address. You can access the switch using IP address of the switch. You can set IP address of the switch manually or using DHCP.

### User Account Management

User Account Management is mainly used to modify the administrator's username and password in order to refuse illegal users.

### Backup and Restore

Backup and Restore is used to download the current configuration and save it as a file to your computer, and upload a backup configuration file to restore your switch to the previous configuration.

### System Reboot

System Reboot is used to reboot the switch.

### System Reset

System Reset is used to reset the switch to the factory default setting. All the settings will be cleared after the switch is reset.

### Firmware Upgrade

To upgrade the firmware is to get more functions and better performance. Go to the website <https://www.tp-link.com> to download the updated firmware.

# 2 Configuring System Info


With system information configuration, you can:

- View the system information
- Specify the device description

## 2.1 Viewing the System Information

Choose the menu **System > System Info** to load the following page. You can view the basic system information of the switch.

Figure 2-1 Viewing the System Summary



The screenshot shows the 'System Info' page with a table of system parameters and a form for editing the device description.


System Info	
Device Description	TL-SG105E
MAC Address	B0:4E:26:A0:FB:87
IP Address	192.168.0.1
Subnet Mask	255.255.255.0
Default Gateway	0.0.0.0
Firmware Version	1.0.0 Build 20171214 Rel.70092
Hardware Version	TL-SG105E 4.0

Below the table, there is a form with a label 'Device Description' and a text input field containing 'TL-SG105E'. To the right of the input field is an 'Apply' button.

## 2.2 Specifying the Device Description

Choose the menu **System > System Info** to load the following page. Specify a new device description for the switch, and click **Apply**.

Figure 2-2 Specifying the Device Description



The screenshot shows the 'System Info' page with the same table as in Figure 2-1. The 'Device Description' field in the form below the table is highlighted, indicating it is the focus of the configuration.

System Info	
Device Description	TL-SG105E
MAC Address	B0:4E:26:A0:FB:87
IP Address	192.168.0.1
Subnet Mask	255.255.255.0
Default Gateway	0.0.0.0
Firmware Version	1.0.0 Build 20171214 Rel.70092
Hardware Version	TL-SG105E 4.0

Below the table, there is a form with a label 'Device Description' and a text input field containing 'TL-SG105E'. To the right of the input field is an 'Apply' button.

# 3 Configuring IP

You can configure the system IP address in the following two ways:

- Configure the System IP Address Using DHCP
- Configure the System IP Address Manually

## Configuring the System IP Address Using DHCP

Choose the menu **System > IP Setting** to load the following page.

Figure 3-1 Configuring System IP Address using DHCP

The screenshot shows the 'IP Address Setting' page. It features a table with four rows: 'DHCP Setting' with a dropdown menu set to 'Enable', 'IP Address' with the value '192.168.0.1', 'Subnet Mask' with '255.255.255.0', and 'Default Gateway' with '0.0.0.0'. Below the table are two buttons: 'Apply' and 'Help'.

DHCP Setting	Enable ▾
IP Address	192.168.0.1
Subnet Mask	255.255.255.0
Default Gateway	0.0.0.0

Apply Help

Follow these steps to configure the system IP address using DHCP:

- 1) Select DHCP setting as **Enable** from the drop-down list.
- 2) Click **Apply**. The switch will obtain IP settings from the DHCP server.

## Configuring the System IP Address Manually

Choose the menu **System > IP Setting** to load the following page.

Figure 3-2 Configuring System IP Address Manually

The screenshot shows the 'IP Address Setting' page. It features a table with four rows: 'DHCP Setting' with a dropdown menu set to 'Disable', 'IP Address' with the value '192.168.0.1', 'Subnet Mask' with '255.255.255.0', and 'Default Gateway' with '0.0.0.0'. Below the table are two buttons: 'Apply' and 'Help'.

DHCP Setting	Disable ▾
IP Address	192.168.0.1
Subnet Mask	255.255.255.0
Default Gateway	0.0.0.0

Apply Help

Follow these steps to configure the system IP address manually:

- 1) Select DHCP setting as **Disable** from the drop-down list.
- 2) Specify the IP address, subnet mask and default gateway.

### IP Address

Specify the system IP of the switch. You can use this IP address to access the switch.



---

Subnet Mask	Specify the subnet mask of the switch..
Default Gateway	Specify the default gateway of the switch.

---

3) Click **Apply**.

# 4 Configuring User Account

With user account management, you can modify the administrator's username and password in order to refuse illegal users.

Choose the menu **System > User Account** to load the following page.

Figure 4-1 Configuring User Account

User Account Setting	
New Username	admin
Old Password	
New Password	
Confirm Password	

Follow these steps to configure the user account:

- 1) Specify the new username, enter the old password, specify a new password and confirm the new password.

<b>New Username</b>	Create a user name for login. The user name should not be more than 16 characters using digits, letters and underlines only.
<b>Old Password</b>	Enter the old password of the switch. By default, the old password is <b>admin</b> .
<b>New Password</b>	Specify a new password for login.
<b>Confirm Password</b>	Retype the new password.

- 2) Click **Apply**.

# 5 Backing up and Restoring the Switch

With backup and restore, you can:

- Save the current configuration.
- Restore to the previous configuration.

## 5.1 Saving the Current Configuration

Choose the menu **System > System Tools > Backup and Restore** to load the following page. In the **Config Backup** section, click **Backup Config** to save the configuration file to your PC.

Figure 5-1 Backing Up the Configuration

The screenshot shows two sections of a web interface. The top section is titled "Config Backup" and contains the text: "Click the Backup Config button to save the current configuration to your computer. You are suggested to save current configuration before backup." Below this text are two buttons: "Backup Config" and "Help". The bottom section is titled "Config Restore" and contains the text: "Select a backup config file and click the Restore Config button, and then you can restore the switch to its previous config." Below this text is a label "Config file:" followed by a "Browse..." button, a text input field containing "No file selected.", a "Restore Config" button, and a "Help" button.


 **Note:**

It will take several minutes to save the configuration file. Wait without any operation.

## 5.2 Restoring to the Previous Configuration

Choose the menu **System > System Tools > Backup and Restore** to load the following page.


Figure 5-2 Restoring the Configuration



Follow these steps to restore the switch to the previous configuration:

- 1) In the **Config Restore** section, click **Browse** to load the following page. Specify the configuration file path and select the configuration file.

Figure 5-3 Choosing the Configuration File



- 2) Click **Open** and the following page will be displayed. In the **Config Restore** section, click **Restore Config** to restore the switch to the previous configuration. It will take effect after the switch automatically reboots.

Figure 5-4 Restoring to the Previous Configuration

The screenshot shows two sections of a web interface. The top section is titled "Config Backup" and contains the text: "Click the Backup Config button to save the current configuration to your computer. You are suggested to save current configuration before backup." Below this text are two buttons: "Backup Config" and "Help". The bottom section is titled "Config Restore" and contains the text: "Select a backup config file and click the Restore Config button, and then you can restore the switch to its previous config." Below this text is a "Config file:" label followed by a text input field containing "105E\_Backup.cfg" and a "Browse..." button. To the right of the input field are two buttons: "Restore Config" and "Help".


 **Note:**

- It will take several minutes to restore the configuration. Wait without any operation.
- To avoid any damage, Do not power down the switch while being restored.
- After being restored, the current configuration of the switch will be lost.

# 6 Rebooting the Switch

Choose the menu **System > System Tools > System Reboot** to load the following page. Click **Reboot**.

Figure 6-1 Rebooting the Switch



 **Note:**

- It will take several minutes to reboot the switch. Wait without any operation while the switch reboots.
- To avoid any damage, do not power down the switch while the switch reboots.

# 7 Resetting the Switch

Choose the menu **System > System Tools > System Reset** to load the following page.


Figure 7-1 Resetting the Switch



Follow these steps to reset the switch.

- 1) Click **Reset**, and the following page will pop up.

Figure 7-2 Being Sure to Reset the Switch



- 2) Click **OK** to reset the switch.

---

 **Note:**


- After the switch is reset, it will reboot automatically.
  - It will take several minutes to reboot the switch. Wait without any operation while the switch reboots.
  - To avoid any damage, do not power down the switch during the reset.
  - After the switch is reset, all the settings will be restored to the default.
-

# 8 Upgrading the Firmware

- For TL-SG105E and TL-SG108E

Choose the menu **System > System Tools > Firmware Upgrade** to load the following page.


Figure 8-1 Being Ready to Upgrade the Firmware



Follow these steps to upgrade the firmware:

- 1) Click **Ready** to load the following page. Then the device will restart.

Figure 8-2 Restarting the Device



- 2) Wait until the device restarts, the following page will be displayed.


Figure 8-3 Upgrading the Firmware





- 3) Click **Browse** to load the following page. Specify the firmware file path and select the firmware to upgrade.

Figure 8-4 Browsing the Firmware File



- 4) Click **Open**. The following page will be displayed. Click **Upgrade**.

Figure 8-5 Upgrading the Firmware



---


 **Note:**

- It will take several minutes to upgrade the firmware. Wait without any operation.
  - Select the proper software version matching with the hardware to upgrade.
  - To avoid damage, do not power down the switch while upgrading the firmware.
  - It is recommended to backup the configuration before upgrading.
- 

■ For TL-SG116E

Choose the menu **System > System Tools > Firmware Upgrade** to load the following page.

Figure 8-6 Being Ready to Upgrade the Firmware



**Firmware Upgrade**

You will get the new function after upgrading the firmware.

Firmware File:  No file chosen


Firmware Version: 1.0.0 Build 20171214 Rel.70092

Hardware Version: TL-SG116E 1.0

Follow these steps to upgrade the firmware:


- 1) Click **Choose File** to load the following page. Specify the firmware file path and select the firmware to upgrade.

Figure 8-7 Browsing the Firmware File



- 2) Click **Open** and the following page will be displayed. Click **Upgrade**.

Figure 8-8 Upgrading the Firmware



---

 **Note:**

- It will take several minutes to upgrade the firmware. Wait without any operation.
  - Select the proper software version matching with the hardware to upgrade.
  - To avoid damage, do not power down the switch while upgrading the firmware.
  - It is recommended to backup the configuration before upgrading.
-

# 9 Appendix: Default Parameters

Default settings of System Info are listed in the following table.

Table 9-1 Default Settings of System Info

Parameter	Default Setting
Device Description	The model name of the switch.

Default settings of IP Setting are listed in the following table.

Table 9-2 Default Settings of IP Address Configuration

Parameter	Default Setting
DHCP Setting	Enable
IP Address	192.168.0.1
Subnet Mask	255.255.255.0
Default Gateway	0.0.0.0

Default settings of User Account are listed in the following table.

Table 9-3 Default Settings of User Account Configuration

Parameter	Default Setting
New Username	admin

# Part 3

## Switching

### CHAPTERS

1. Switching
2. Configuring Ports
3. Configuring IGMP Snooping
4. Configuring LAG
5. Configuration Examples
6. Appendix: Default Parameters

# 1 Switching

## 1.1 Overview

With the switching feature, you can configure port setting, IGMP Snooping and LAG.

## 1.2 Supported Features

The switch supports the following features about switching:

### Port Setting

You can configure port status, speed, duplex mode and flow control for ports.

### IGMP Snooping

In a point-to-multipoint network, packets can be sent in three ways: unicast, broadcast and multicast. With unicast, many copies of the same information will be sent to all the receivers, occupying a large bandwidth.


With broadcast, information will be sent to all users in the network no matter they need it or not, wasting network resources and impacting information security.

Multicast, however, solves all the problems caused by unicast and broadcast. With multicast, the source only needs to send one piece of information, and all and only the users who need the information will receive copies of the information. In a point-to-multipoint network, multicast technology not only transmits data with high efficiency, but also saves a large bandwidth and reduces network load.

When IGMP Snooping is disabled on the switch, multicast packets will be broadcast in the Layer 2 network; when IGMP Snooping is enabled on the switch, multicast data from

a known multicast group will be transmitted to the designated receivers instead of being broadcast in the Layer2 network. The following figure shows how IGMP snooping works.

Figure 1-1 IGMP Snooping



## LAG

With LAG (Link Aggregation Group) function, you can aggregate multiple physical ports into a logical interface to increase link bandwidth and enhance the connection reliability.



# 2 Configuring Ports

Choose the menu **Switching > Port Setting** to load the following page.

Figure 2-1 Configuring Ports

**Port Setting**

Port	Status	Speed/Duplex	Flow Control
Port 1 ▲			
Port 2			
Port 3	▼	▼	▼
Port 4			
Port 5 ▼			

---

Port	Status	Speed/Duplex		Flow Control	
		Config	Actual	Config	Actual
Port 1	Enabled	Auto	Link Down	Off	Off
Port 2	Enabled	Auto	Link Down	Off	Off
Port 3	Enabled	Auto	Link Down	Off	Off
Port 4	Enabled	Auto	1000MF	Off	Off
Port 5	Enabled	Auto	Link Down	Off	Off

Follow these steps to configure the port parameters.

- 1) Select the desired ports and set basic parameters for the ports.

**Status** Enable or disable the port. With this option enabled, the port forwards packets normally. Otherwise, the port cannot work. By default, it is enabled.

**Speed/Duplex** Select the appropriate speed and duplex mode for the port. When **Auto** is selected, the port automatically negotiates speed mode with the connected device. It is recommended to select **Auto** if both ends of the link support auto-negotiation.

**Flow Control** Select **On** or **Off** to enable or disable the Flow Control feature. When Flow Control is enabled, when the switch gets overloaded, it will send a PAUSE frame to notify the peer device to stop sending data for a specific period of time, thus avoiding the packet loss caused by congestion.

- 2) Click **Apply**.

---

 **Note:**

- It is recommended to set the ports on both ends of a link with the same speed and duplex mode.
  - Keep the port that is connected to the management device enabled, or you cannot access the switch.
  - The parameters of the port members in a LAG should be set as the same.
-

# 3 Configuring IGMP Snooping

Choose the menu **Switching > IGMP Snooping** to load the following page.

Figure 3-1 Configuring IGMP Snooping

**IGMP Snooping**

IGMP Snooping:  Enable  Disable

Report Message Suppression:  Enable  Disable

IP Address	VLAN ID	Ports
------------	---------	-------

Follow these steps to configure IGMP Snooping.

- 1) Enable IGMP Snooping. Enable or disable report message suppression according to your needs. Click **Apply**.

<b>IGMP Snooping</b>	Enable or disable IGMP Snooping globally.
<b>Report Message Suppression</b>	Enable or disable Report Message Suppression globally. When enabled, the switch will only forward the first IGMP report message for each multicast group to the IGMP querier during one query interval, and suppress subsequent IGMP report messages for the same multicast group. This feature prevents duplicate report messages from being sent to the IGMP querier.

- 2) In the table below, you can view the current IGMP group information.

<b>IP Address</b>	Displays the IP address of the multicast group.
<b>VLAN ID</b>	Displays the VLAN ID of the multicast group. All port members of a multicast group should be included in the same VLAN.
<b>Ports</b>	Displays the forwarding port list of the multicast group.

# 4 Configuring LAG

Choose the menu **Switching > LAG** to load the following page.

Figure 4-1 Configuring LAG

### Static LAG Setting

Group ID	Port
LAG 1 ▼	Port 1 ▲ Port 2 Port 3 Port 4 ▼

---

Group ID	Ports	Select
LAG 1	---	<input type="checkbox"/>

Follow these steps to configure LAG:

- 1) Select the desired LAG group from the drop-down list.
- 2) Click the ports to add to the LAG group. Click **Apply**.
- 3) In the table below, you can verify the LAG configuration result. You can select the LAG and click **Delete** to delete ports from the LAG group.

Group ID	Displays the ID of the LAG group.
Ports	Displays the LAG member ports.

#### Note:

- It is recommended to configure the LAG function before configuring the other functions for the member ports.
- Ensure that devices on both ends of the aggregation link use the same number of physical ports with the same speed and duplex mode, flow control setting and QoS setting.
- Mirroring and mirrored port cannot be added to an LAG group.
- The max number of LAG groups that the switch can support is as follows:  
1 for TL-SG105E; 2 for TL-SG108E; 8 for TL-SG116E
- Each LAG group has 2 port members at least and 4 port members at most.

# 5 Configuration Examples


## 5.1 Example for Configuring IGMP Snooping

### 5.1.1 Network Requirements

Host B, Host C and Host D are in the same VLAN of the switch. All of them want to receive multicast streams sent to the same multicast group.

As shown in the following topology, Host B, Host C and Host D are connected to port 1, port 2 and port 3 respectively. Port 4 is the router port connected to the multicast querier.

Figure 5-1 Network Topology for Basic IGMP Snooping



### 5.1.2 Configuration Scheme

- Configure 802.1Q VLAN. Add the three member ports and the router port to the same VLAN.
- Enable IGMP Snooping.

Demonstrated with TL-SG105E, the following section provides configuration steps.

### 5.1.3 Configuration Steps

- 1) Choose the menu **VLAN > 802.1Q VLAN** to load the following page. Select the 802.1Q VLAN Configuration as **Enable**. Click **Apply**. Specify the VLAN ID as **2**. Specify the VLAN name as **VLAN2**. Select port 1, port 2, port 3 as untagged ports. Select port 4 as a tagged port. Click **Add/Modify**.

Figure 5-2 Configuring 802.1Q VLAN

#### 802.1Q VLAN Configuration

802.1Q VLAN Configuration:  Enable  Disable

VLAN ID	1-4094)		VLAN Name	VLAN2
Port	Untagged	Tagged	Not Member	
Select All	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
Port 1	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	
Port 2	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	
Port 3	<input checked="" type="radio"/>	<input type="radio"/>	<input type="radio"/>	
Port 4	<input type="radio"/>	<input checked="" type="radio"/>	<input type="radio"/>	
Port 5	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>	

VLAN ID	VLAN Name	Member Ports	Tagged Ports	Untagged Ports	Delete
1	Default	1-5		1-5	<input type="checkbox"/>

- 2) Choose the menu **VLAN > 802.1Q PVID Setting** to load the following page. Select port 1, port 2, port 3 and port 4, and specify the PVID as 2 for the ports. Click **Apply**.

Figure 5-3 Configuring 802.1Q PVID

#### 802.1Q VLAN PVID Setting

Select	Port	PVID
<input type="checkbox"/>		2
<input checked="" type="checkbox"/>	Port 1	2
<input checked="" type="checkbox"/>	Port 2	2
<input checked="" type="checkbox"/>	Port 3	2
<input checked="" type="checkbox"/>	Port 4	2
<input type="checkbox"/>	Port 5	1

- 3) Choose the menu **Switching > IGMP Snooping** to load the following page. Enable IGMP snooping. Click **Apply**.

Figure 5-4 Configuring IGMP Snooping

### IGMP Snooping

IGMP Snooping:  Enable  Disable

Report Message Suppression:  Enable  Disable


IP Address	VLAN ID	Ports

## 5.2 Example for Configuring LAG

### 5.2.1 Network Requirements

As shown below, hosts and servers are connected to Switch A and Switch B, and heavy traffic is transmitted between the two switches. To achieve high speed and reliability of data transmission, you can bundle multiple physical ports into one logical interface. In this case, we bundle port 1, port 2 and port 3 of both switches into one logical interface.

Figure 5-5 Network Topology for LAG



Demonstrated with TL-SG105E, the following section provides configuration steps. The configuration steps are similar for both switches, here we take Switch A for example.

### 5.2.2 Configuration Steps

Choose the menu **Switching > LAG** to load the following page. Add Port 1, Port 2 and Port 3 to LAG 1. Click **Apply**.

Figure 5-6 Configuring LAG

### Static LAG Setting

Group ID	Port
LAG 1 ▼	<div style="border: 1px solid gray; padding: 2px;">           Port 1            Port 2            Port 3            Port 4 ▼         </div>

# 6 Appendix: Default Parameters

Default settings of Port are listed in the following table.

Table 6-1 Default Settings of Port Configuration

Parameter	Default Setting
Status	Enabled
Speed/Duplex	Auto
Flow Control	Off

Default settings of IGMP Snooping are listed in the following table.

Table 6-2 Default Settings of IGMP Snooping Configuration

Parameter	Default Setting
IGMP Snooping	Enable
Report Message Suppression	Disable

Default settings of LAG are listed in the following table.

Table 6-3 Default Settings of LAG Configuration

Parameter	Default Setting
Group ID	LAG 1



# Part 4

## Monitoring

### CHAPTERS

1. Monitoring
2. Viewing Port Statistics
3. Configuring Port Mirror
4. Testing Cables
5. Configuring Loop Prevention
6. Appendix: Default Parameters

# 1 Monitoring

## 1.1 Overview

With the monitoring feature, you can monitor the traffic on the switch.

## 1.2 Supported Features

### Port Statistics

Port Statistics is used to display the information of each port, which facilitates you to monitor the traffic and locate faults promptly.

### Port Mirror

Port Mirror is used to monitor network traffic by forwarding copies of incoming and outgoing packets from one or multiple ports (mirrored ports) to a specified port (mirroring port). Generally, the mirroring port is connected to a data diagnosis device, which is used to analyze the mirrored packets for monitoring and troubleshooting the network.

### Cable Test

This switch provides cable test to diagnose the connection status of the cable connected to the switch and the distance to the problem location, which facilitates you to locate and diagnose the trouble spot of the network.

### Loop Prevention

With loop prevention feature enabled, the switch can detect loops using loop detection packets. When a loop is detected, the switch will block the corresponding port automatically.

## 2 Viewing Port Statistics

Choose the menu **Monitoring > Port Statistics** to load the following page.

Figure 2-1 Viewing Port Statistics

Port Statistics Info						
Port	Status	Link Status	TxGoodPkt	TxBadPkt	RxGoodPkt	RxBadPkt
Port 1	Enabled	Link Down	0	0	0	0
Port 2	Enabled	Link Down	0	0	0	0
Port 3	Enabled	Link Down	85	0	0	0
Port 4	Enabled	1000Full	339	0	1087	0
Port 5	Enabled	Link Down	0	0	0	0

You can view the statistics of each port. You can click **Clear** to clear the data, also you can click **Refresh** to refresh the data.

Port	Displays the port number of the switch.
Status	Displays whether the port is enabled or disabled.
Link Status	Displays the link state of the port.
TxGoodPkt	Displays the number of packets transmitted on the port. Error packets are not counted in.
TxBadPkt	Displays the number of error packets transmitted on the port.
RxGoodPkt	Displays the number of packets received on the port. Error packets are not counted in.
RxbadPkt	Displays the number of error packets received on the port.

### Note:

- The frames with more than 1518 bytes, less than 64 bytes or with bad FCS (Frame Check Sequence) are recorded as BadPkts.
- Because of the supporting feature of jumbo frame, the frames with more than 1518 bytes and less than 10000 bytes will be recorded as GoodPkts and BadPkts at the same time, and can be forwarded normally.

# 3 Configuring Port Mirror

Choose the menu **Monitoring > Port Mirror** to load the following page.

Figure 3-1 Configuring Port Mirror

### Port Mirror

Port Mirror	Mirroring Port
Disable ▼	▼

---

### Mirrored Port

Mirrored Port	Ingress	Egress
<div style="border: 1px solid gray; padding: 2px;">           Port 1 ▲            Port 2            Port 3            Port 4            Port 5 ▼         </div>	▼	▼

---

Mirrored Port	Ingress	Egress
Port1	Disable	Disable
Port2	Disable	Disable
Port3	Disable	Disable
Port4	Disable	Disable
Port5	Disable	Disable

Follow these steps to configure port mirror:

- 1) Enable the port mirror feature globally. Specify a mirroring port. Click **Apply**.

<b>Port Mirror</b>	Enable or disable the port mirror feature globally.
--------------------	---

<b>Mirroring Port</b>	Select a port as the mirroring port. Traffic passing through the mirrored ports will be mirrored to the mirroring port.
-----------------------	---

- 2) Select one or more mirrored ports, enable or disable the ingress packets and egress packets to be mirrored for the ports. Click **Apply**.

<b>Mirrored Port</b>	Select one or more ports as mirrored ports. Traffic passing through the mirrored ports will be mirrored to the mirroring port.
----------------------	--

---

Ingress	For each port, select whether the ingress packets are mirrored. With this option enabled, the packets received by the port will be copied to the mirroring port. With this option disabled, the packets received by the port will not be copied to the mirroring port.
---------	--

---

Egress	For each port, select whether the egress packets are mirrored. With this option enabled, the packets sent by the port will be copied to the mirroring port. With this option disabled, the packets sent by the port will not be copied to the mirroring port.
--------	---

---

3) In the table below, you can verify the configuration result for port mirroring.

---

 **Note:**

The LAG member ports cannot be set as a mirroring port or mirrored port.

---

# 4 Testing Cables

Choose the menu **Monitoring > Cable Test** to load the following page.

Figure 4-1 Testing Cables

**Cable Test**

Select	Port	Test Result	Cable Fault Distance(m)
<input type="checkbox"/>	Port 1	--	--
<input type="checkbox"/>	Port 2	--	--
<input type="checkbox"/>	Port 3	--	--
<input type="checkbox"/>	Port 4	--	--
<input type="checkbox"/>	Port 5	--	--

Follow these steps to diagnose the cable:


- 1) Select your desired ports for test. Click **Apply** to test cables connected to the selected ports.
- 2) Check the test results in the table.

<b>Port</b>	Displays the port number.
<b>Test Result</b>	<p>Displays the cable status. Test results include normal, close (or short), open and crosstalk.</p> <p><b>Normal</b> : The cable is connected normally.</p> <p><b>Close (or short)</b>: A short circuit is being caused by abnormal contact of wires in the cable.</p> <p><b>Open</b>: No device is connected to the other end or the connection is broken.</p> <p><b>Crosstalk</b>: Impedance mismatch due to the poor quality of the cable.</p>
<b>Cable Fault Distance (m)</b>	Displays the length from the port to the trouble spot, if the connection status is short, close (or short) or crosstalk.

# 5 Configuring Loop Prevention

Choose the menu **Monitoring > Loop Prevention** to load the following page.

Figure 5-1 Configuring Loop Prevention



The screenshot shows a web interface titled "Loop Prevention Setting". It features a central configuration area with a "Loop Prevention" label and a dropdown menu currently set to "Enable". Below this are two buttons: "Apply" and "Help".

Follow these steps to configure loop prevention:

- 1) Enable or disable loop prevention.

---

**Loop Prevention**    Enable or disable the loop prevention feature globally.

---

- 2) Click **Apply**.

# 6 Appendix: Default Parameters

Default settings of Port Mirror are listed in the following table.

Table 6-1 Default Settings of Port Mirror Configuration

Parameter	Default Setting
Port Mirror	Disable

Default settings of Loop Prevention are listed in the following table.

Table 6-2 Default Settings of Loop Prevention Configuration

Parameter	Default Setting
Loop Prevention	Enable



# Part 5

## Configuring VLAN

### CHAPTERS

1. Overview
2. Configuring MTU VLAN
3. Configuring Port Based VLAN
4. Configuring 802.1Q VLAN
5. Configuration Example for 802.1Q VLAN
6. Appendix: Default Parameters

# 1 Overview

VLAN (Virtual Local Area Network) is a network technique that solves broadcasting issues in local area networks. It is usually applied in the following occasions:

- To restrict broadcast domain: VLAN technique divides a big local area network into several VLANs, and all VLAN traffic remains within its VLAN. It reduces the influence of broadcast traffic in Layer 2 network to the whole network.
- To enhance network security: Devices from different VLANs cannot achieve Layer 2 communication, and thus users can group and isolate devices to enhance network security.
- For easier management: VLANs group devices logically instead of physically, so devices in the same VLAN need not be located in the same place. It eases the management of devices in the same work group but located in different places.

There are 3 types of VLAN modes supported on the switch:

- MTU VLAN

MTU VLAN (Multi-Tenant Unit VLAN) defines an uplink port which will build up several VLANs with each of the other ports. Each VLAN contains two ports, the uplink port and one of the other ports in the switch, so the device connected to the uplink port can communicate with the device connected to any other port, but devices connected to other ports cannot communicate with each other.

- Port Based VLAN

VLANs are divided based on ports. In port based VLAN mode, each port can only be added to one VLAN.

- 802.1Q VLAN

The IEEE 802.1Q protocol defines a new format of VLAN data frame (Tagged Frame). As the following figure shows, compared to the traditional Ethernet data frame (Untagged Frame), the VLAN data frame (Tagged Frame) adds a VLAN tag.

Traditional Ethernet data frame (Untagged Frame)

Distination Address	Source Address	Length/ Type	Data	FCS
---------------------	----------------	--------------	------	-----

VLAN data frame (Tagged Frame)

Distination Address	Source Address	VLAN Tag	Length/ Type	Data	FCS
---------------------	----------------	----------	--------------	------	-----

On receiving a tagged frame, the switch checks the VID (VLAN ID) contained in the VLAN tag to determine which VLAN the frame belongs to. On receiving an untagged frame, the

switch will first insert a VLAN tag to the frame, using the PVID (Port VLAN ID) of the port as its VID, and then forward it as a tagged frame.

---

 **Note:**

The switch works in one and only one VLAN mode at any time. When a specific VLAN mode is enabled, the other two VLAN modes will be disabled automatically and the corresponding VLAN configuration will be lost.

---

## 2 Configuring MTU VLAN

Choose the menu **VLAN > MTU VLAN** to load the following page.

Figure 2-1 Configuring MTU VLAN

**MTU VLAN Configuration**

MTU VLAN Configuration:  Enable  Disable Apply

Current Uplink Port:	1
Change Uplink Port:	Port 1 ▼

Apply Help

Follow these steps to configure MTU VLAN:

- 1) Select MTU VLAN configuration as **Enable**. Click **Apply**.

---

<b>MTU VLAN Configuration</b>	Enable or disable the MTU VLAN mode.
-------------------------------	--------------------------------------

---

- 2) In the table below, change the uplink port from the drop-down list according to your needs. Click **Apply**.

---

<b>Change Uplink Port</b>	Select the desired uplink port from the drop-down list. The uplink port will build up several VLANs with each of the other ports.
---------------------------	---

---

# 3 Configuring Port Based VLAN

Choose the menu **VLAN > Port Based VLAN** to load the following page.

Figure 3-1 Configuring Port Based VLAN

### Port Based VLAN Configuration

Port Based VLAN Configuration:  Enable  Disable

VLAN ID	(2-5)				
Port	1	2	3	4	5
Member	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

VLAN ID	VLAN Member Port	Delete
1	1-5	<input type="checkbox"/>

Follow these step to configure port based VLAN:

- 1) Select the port based VLAN configuration as **Enable**. Click **Apply**.

---

**Port Based VLAN Configuration**      Enable or disable the port based VLAN mode.

- 2) Select the ID for the VLAN and ports to add to the VLAN. Click **Apply**.

---

**VLAN ID**      Select the ID for the VLAN which you want to add ports to.

---

**Member**      Select the ports to add to the VLAN.

- 3) In the table below, you can verify the configuration result of port based VLAN. You can delete a VLAN as you wish by selecting the VLAN and clicking **Delete**.

---

 **Note:**

- By default, all the ports are added to VLAN 1.
  - Once a port is added to another VLAN, it is deleted from the original VLAN automatically.
  - Once a port is removed from all the other VLANs, it is added to VLAN 1 automatically.
  - VLAN 1 includes at least one port and cannot be deleted.
-

# 4 Configuring 802.1Q VLAN

To complete the 802.1Q configuration, follow these steps:

- 1) Configure the VLAN, including creating a VLAN and adding the ports to the VLAN.
- 2) Configure the PVID.

## 4.1 Configuring the VLAN

Choose the menu **VLAN > 802.1Q VLAN** to load the following page.

Figure 4-1 Configuring 802.1Q VLAN

### 802.1Q VLAN Configuration

802.1Q VLAN Configuration:  Enable  Disable Apply

VLAN ID	(1-4094)	VLAN Name	(1-4094)
Port	Untagged	Tagged	Not Member
Select All	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Port 1	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>
Port 2	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>
Port 3	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>
Port 4	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>
Port 5	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>

Add/Modify
Help

VLAN ID	VLAN Name	Member Ports	Tagged Ports	Untagged Ports	Delete
1	Default	1-5		1-5	<input type="checkbox"/>

Select All
Delete

Follow these steps to configure the VLAN:

- 1) Select the 802.1Q VLAN Configuration as **Enable**. Click **Apply**.

---

**802.1Q VLAN Configuration**      Enable or disable the 802.1Q VLAN mode.

---

- 2) Enter a VLAN ID and a VLAN name for identification. Select the untagged port(s) and the tagged port(s) respectively to add to the created VLAN based on the network topology. Click **Add/Modify**.

---

**VLAN ID**      Enter a VLAN ID, which ranges from 1 to 4094.

---

VLAN Name	Enter a VLAN name for identification. The VLAN name should not be more than 10 characters using digits, letters, hyphens and underlines only.
Untagged / Tagged / Not Member	<p>Set the port as an untagged port, as a tagged port or not as a member port in the VLAN.</p> <p><b>Untagged:</b> Select the egress rule of the port as Untagged. An untagged port will forward frames after removing the VLAN tags.</p> <p><b>Tagged:</b> Select the egress rule of the port as Tagged. A tagged port will forward frames with the current VLAN tags remained.</p> <p><b>Not Member:</b> The port that is not selected as a member will not forward frames in the target VLAN.</p>

3) In the table below, you can verify the configuration result of 802.1Q VLAN. You can delete a VLAN as you wish by selecting the VLAN and clicking **Delete**.


 **Note:**

- By default, all the ports are added to VLAN 1.
- The port can be removed from VLAN 1 only when the port is also a member of the other VLANs.
- Once a port is removed from all the current VLANs, it is added to VLAN 1 automatically.
- VLAN 1 cannot be deleted.

## 4.2 Configuring the PVID

Choose the menu **VLAN > 802.1Q PVID Setting** to load the following page.

Figure 4-2 Configuring 802.1Q PVID



Follow these steps to configure the PVID:

1) Select the ports and set the PVID for the ports.

PVID	Set the PVID for the ports. The PVID ranges from 1 to 4094.
------	---

2) Click **Apply**.

---

 **Note:**

- The PVID configuration will take effect only when 802.1Q VLAN mode is enabled.
  - You can specify a PVID only when the corresponding VLAN exists.
-



# 5 Configuration Example for 802.1Q VLAN

## 5.1 Network Requirements

- Offices of Department A and Department B in the company are located in different places, and some computers in different offices are connected to the same switch.
- It is required that computers can communicate with each other in the same department but not with computers in the other department.


## 5.2 Configuration Scheme

- Divide computers in Department A and Department B into two VLANs respectively so that computers can communicate with each other in the same department but not with computers in the other department.
- Terminal devices like computers usually do not support VLAN tags. Add untagged ports to the corresponding VLANs and specify the PVID.
- The intermediate link between two switches carries traffic from two VLANs simultaneously. Add the tagged ports to both VLANs.

### 5.3 Network Topology

The figure below shows the network topology. Host A1 and Host A2 are in Department A, while Host B1 and Host B2 are in Department B. Switch A and Switch B are located in two different places. Host A1 and Host B1 are connected to port 2 and port 3 on Switch A respectively, while Host A2 and Host B2 are connected to port 2 and port 3 on Switch B respectively. Port 4 on Switch A is connected to port 4 on Switch B.

Figure 5-1 Network Topology



## 5.4 Configuration Steps

Demonstrated with TL-SG105E, the following section provides configuration steps. The configuration steps on both switches are similar, here we take Switch A for example.

- 1) Choose the menu **VLAN > 802.1Q VLAN** to load the following page. Select 802.1Q VLAN configuration as **Enable**. Click **Apply**.

Figure 5-2 Configuring 802.1Q VLAN

### 802.1Q VLAN Configuration

802.1Q VLAN Configuration:  Enable  Disable

VLAN ID	(1-4094)	VLAN Name	(1-4094)
Port	Untagged	Tagged	Not Member
Select All	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Port 1	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>
Port 2	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>
Port 3	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>
Port 4	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>
Port 5	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>

VLAN ID	VLAN Name	Member Ports	Tagged Ports	Untagged Ports	Delete
1	Default	1-5		1-5	<input type="checkbox"/>

- 2) Choose the menu **VLAN > 802.1Q VLAN** to load the following page. Specify the VLAN ID as **2**, specify the VLAN name as **Dept\_A**. Add port 2 to the VLAN as an untagged port. Add port 4 to the VLAN as a tagged port. Click **Add/Modify**.

Figure 5-3 Creating VLAN 2 and Adding Ports to the VLAN

### 802.1Q VLAN Configuration

802.1Q VLAN Configuration:  Enable  Disable

VLAN ID	<input style="border: 1px solid red;" type="text" value="2"/> (-4094)	VLAN Name	<input style="border: 1px solid red;" type="text" value="Dept_A"/>
Port	Untagged	Tagged	Not Member
Select All	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Port 1	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>
Port 2	<input checked="" style="border: 1px solid red;" type="radio"/>	<input type="radio"/>	<input type="radio"/>
Port 3	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>
Port 4	<input type="radio"/>	<input checked="" style="border: 1px solid red;" type="radio"/>	<input type="radio"/>
Port 5	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>

VLAN ID	VLAN Name	Member Ports	Tagged Ports	Untagged Ports	Delete
1	Default	1-5		1-5	<input type="checkbox"/>

- 3) Choose the menu **VLAN > 802.1Q VLAN** to load the following page. Specify the VLAN ID as **3**, specify the VLAN name as **Dept\_B**. Add port 3 to the VLAN as an untagged port. Add port 4 to the VLAN as a tagged port. Click **Add/Modify**.

Figure 5-4 Creating VLAN 3 and Adding Ports to the VLAN

### 802.1Q VLAN Configuration

802.1Q VLAN Configuration:  Enable  Disable

VLAN ID	<input style="border: 1px solid red;" type="text" value="3"/> (1-4094)	VLAN Name	<input style="border: 1px solid red;" type="text" value="Dept_B"/>
Port	Untagged	Tagged	Not Member
Select All	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Port 1	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>
Port 2	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>
Port 3	<input checked="" style="border: 1px solid red;" type="radio"/>	<input type="radio"/>	<input type="radio"/>
Port 4	<input type="radio"/>	<input checked="" style="border: 1px solid red;" type="radio"/>	<input type="radio"/>
Port 5	<input type="radio"/>	<input type="radio"/>	<input checked="" type="radio"/>

VLAN ID	VLAN Name	Member Ports	Tagged Ports	Untagged Ports	Delete
1	Default	1-5		1-5	<input type="checkbox"/>
2	Dept_A	2,4	4	2	<input type="checkbox"/>

- 4) Choose the menu **VLAN > 802.1Q VLAN PVID Setting** to load the following page. Specify the PVID of port 2 as 2 and click **Apply**. Specify the PVID of port 3 as 3 and click **Apply**.

Figure 5-5 Configuring 802.1Q PVID

### 802.1Q VLAN PVID Setting

Select	Port	PVID
<input type="checkbox"/>		<input style="border: 1px solid red;" type="text" value="3"/>
<input type="checkbox"/>	Port 1	1
<input style="border: 1px solid red;" type="checkbox"/>	Port 2	<input style="border: 1px solid red;" type="text" value="2"/>
<input checked="" style="border: 1px solid red;" type="checkbox"/>	Port 3	<input style="border: 1px solid red;" type="text" value="3"/>
<input type="checkbox"/>	Port 4	1
<input type="checkbox"/>	Port 5	1

# 6 Appendix: Default Parameters

Default settings of VLAN are listed in the following tables.

Table 6-1 Default Settings of MTU VLAN Configuration

Parameter	Default Setting
MTU VLAN Configuration	Disable

Table 6-2 Default Settings of Port Based VLAN Configuration

Parameter	Default Setting
Port Based VLAN Configuration	Enable
VLAN ID	1
VLAN Member Port	1-5

Table 6-3 Default Settings of 802.1Q VLAN Configuration

Parameter	Default Setting
802.1Q VLAN Configuration	Disable

Table 6-4 Default Settings of 802.1Q VLAN PVID Configuration

Parameter	Default Setting
PVID	1

# Part 6

## Configuring QoS

### CHAPTERS

1. QoS
2. Configuring Basic QoS
3. Configuring Bandwidth Control
4. Configuring Storm Control
5. Configuration Example for Basic QoS
6. Appendix: Default Parameters

# 1 QoS

## 1.1 Overview

With network scale expanding and applications developing, internet traffic is dramatically increased, thus resulting in network congestion, packet drops and long transmission delay. Typically, networks treat all traffic equally on FIFO (First In First Out) delivery basis, but nowadays many special applications like VoD, video conferences, VoIP, etc. require more bandwidth or shorter transmission delay to guarantee the performance.

With QoS (Quality of Service) technology, you can classify and prioritize network traffic to provide differentiated services for certain types of traffic.

## 1.2 Supported Features

With the QoS feature, You can configure QoS Basic, Bandwidth Control and Storm Control on the switch to maximize the network performance and bandwidth utilization.

### QoS Basic

The switch classifies the ingress packets, maps the packets to different priority queues and then forwards the packets to implement QoS function.

### Bandwidth Control

Bandwidth Control functions to control the ingress traffic rate and egress traffic rate on each port via configuring the available bandwidth of each port. In this way, the network bandwidth can be reasonably distributed and utilized.

### Storm Control

Storm Control function allows the switch to monitor broadcast packets, multicast packets and UL-frames (Unknown unicast frames) in the network. If the transmission rate of the packets exceeds the limit, the packets will be automatically discarded to avoid network broadcast storm.



# 2 Configuring Basic QoS

## Configuration Guidelines

Select the QoS mode according to your network requirements. Three QoS modes are supported on the switch: Port Based, 802.1P Based and DSCP Based.

- Port Based

The port based QoS mode supports four priority queues, which are labeled as 1 (Lowest), 2 (Normal), 3 (Medium) and 4 (Highest).

In this mode, the switch prioritizes packets according to their ingress ports, regardless of the packet field or type.

- 802.1P Based

802.1P defines the first three bits in 802.1Q Tag as PRI field. The PRI values are from 0 to 7. The tagged packets are mapped to 4 priority levels based on the PRI value (Lowest=1, 2; Normal=0, 3; Medium=4, 5; Highest=6, 7).

In this mode, the switch only prioritizes packets with VLAN tag, regardless of the IP header of the packets.

- DSCP/802.1P Based

DSCP priority determines the priority of packets based on the ToS (Type of Service) field in their IP header. RFC2474 re-defines the ToS field in the IP packet header as DS field. The first six bits of the DS field is used to represent DSCP priority. The DSCP values are from 0 to 63. The IP packets are mapped to 4 priority levels based on the DSCP value (Lowest=0-15; Normal=16-31; Medium=32-47; Highest=48-63).

In this mode, the switch prioritizes packets with IP header based on DSCP priority first. Then, the switch prioritizes packets with VLAN tag but without IP header base on the PRI field. Finally, the switch prioritizes packets without VLAN tag or IP header based on port priority.

## 2.1 Configuring QoS in Port Based Mode

Choose the menu **QoS > QoS Basic** to load the following page.

Figure 2-1 Configuring Basic QoS in Port Based Mode

**Global Config**

QoS Mode:  Port Based  802.1P Based  DSCP/802.1P Based

**Port-based Priority Setting**

Select	Port	Priority Queue
<input type="checkbox"/>		1(Lowest) ▾
<input type="checkbox"/>	Port 1	1(Lowest)
<input type="checkbox"/>	Port 2	1(Lowest)
<input type="checkbox"/>	Port 3	1(Lowest)
<input type="checkbox"/>	Port 4	1(Lowest)
<input type="checkbox"/>	Port 5	1(Lowest)

Follow these steps to configure QoS in port based mode:

- 1) In the **Global Config** section, select QoS mode as **Port Based**. Click **Apply**.

### QoS Mode

Select the QoS mode.

**Port Based:** In port based mode, the switch prioritizes packets according to their ingress ports, regardless of the packet field or type.

- 2) In the **Port-based Priority Setting** section, select the desired ports and specify the priority queue for the ports. Click **Apply**.

### Priority Queue

Specify the priority queue that the packets from the port are mapped to. The priorities are labeled as 1, 2, 3 and 4. Among them, the bigger value means the higher priority.

## 2.2 Configuring QoS in 802.1P Based Mode

Choose the menu **QoS > QoS Basic** to load the following page.

Figure 2-2 Configuring Basic QoS in 802.1P Based Mode

**Global Config**

QoS Mode:  Port Based  802.1P Based  DSCP/802.1P Based

Follow these steps to configure QoS in 802.1P based mode:

- 1) Select QoS mode as **802.1P Based**.

#### QoS Mode

Select the QoS mode.


**802.1P Based:** In 802.1P based mode, the tagged packets are mapped to 4 priority levels based on the Pri value in 802.1Q tag (Lowest = 1, 2; Normal = 0, 3; Medium = 4, 5; Highest = 6, 7). The switch only prioritizes packets with VLAN tag, regardless of the IP header of the packets.

- 2) Click **Apply**.

## 2.3 Configuring QoS in DSCP Based Mode

Choose the menu **QoS > QoS Basic** to load the following page.

Figure 2-3 Configuring Basic QoS in DSCP Based Mode



The screenshot shows a configuration window titled "Global Config". Inside, there is a "QoS Mode:" label followed by three radio button options: "Port Based", "802.1P Based", and "DSCP/802.1P Based". The "DSCP/802.1P Based" option is selected. To the right of these options are two buttons: "Apply" and "Help".

Follow these steps to configure QoS in DSCP based mode:

- 1) Select QoS mode as **DSCP Based**.

#### QoS Mode

Select the QoS mode from the drop-down list.

**DSCP/802.1P Based:** In DSCP based mode, the IP packets are mapped to 4 priority levels based on the DSCP value (Lowest = 0-15; Normal = 16-31; Medium = 32-47; Highest = 48-63). The switch prioritizes packets with IP header based on DSCP priority first. Then, the switch prioritizes packets with VLAN tag but without IP header based on the PRI field. Finally, the switch prioritizes packets without VLAN tag or IP header based on port priority.

- 2) Click **Apply**.

# 3 Configuring Bandwidth Control

Choose the menu **QoS > Bandwidth Control** to load the following page.

Figure 3-1 Configuring Bandwidth Control

**Bandwidth Control Setting**

Select	Port	Ingress Rate(Kbps)	Egress Rate(Kbps)
<input type="checkbox"/>		<input style="width: 80px;" type="text"/> (0-1000000)	<input style="width: 80px;" type="text"/> (0-1000000)
<input type="checkbox"/>	Port 1	Unlimited	Unlimited
<input type="checkbox"/>	Port 2	Unlimited	Unlimited
<input type="checkbox"/>	Port 3	Unlimited	Unlimited
<input type="checkbox"/>	Port 4	Unlimited	Unlimited
<input type="checkbox"/>	Port 5	Unlimited	Unlimited

Follow these steps to configure bandwidth control:

- 1) Select the desired ports and configure the ingress rate and egress rate for the ports.

**Ingress Rate (Kbps)**

Configure the bandwidth for receiving packets on the port. If the rate for receiving packets on the port exceeds the ingress rate, the packets will be discarded.

**Egress Rate (Kbps)**

Configure the bandwidth for sending packets on the port. If the rate for sending packets on the port exceeds the egress rate, the packets will be discarded.

- 2) Click **Apply**.

 **Note:**

- For a port, the ingress rate control feature and the storm control feature cannot be enabled at the same time. If you enable ingress rate control for a port, storm control will be disabled for that port automatically.
- When egress rate is set for one or more ports, it is recommended to disable the flow control on each port to ensure the switch works normally.
- For ports in the same LAG, bandwidth control should be configured the same to ensure a successful port aggregation.

# 4 Configuring Storm Control

Choose the menu **QoS > Storm Control** to load the following page.

Figure 4-1 Configuring Storm Control

**Storm Control Setting**

Select	Port	Status	Total Rate(Kbit/sec)	Included Storm Type
<input type="checkbox"/>		Disable ▾	<input style="width: 50px;" type="text"/> (1-1000000)	UL-Frame ▲ Multicast Broadcast ▼
<input type="checkbox"/>	Port 1	Disable	Unlimited	
<input type="checkbox"/>	Port 2	Disable	Unlimited	
<input type="checkbox"/>	Port 3	Disable	Unlimited	
<input type="checkbox"/>	Port 4	Disable	Unlimited	
<input type="checkbox"/>	Port 5	Disable	Unlimited	

Follow these steps to configure storm control:

- 1) Select the desired ports and configure the upper rate limit for forwarding broadcast packets, multicast packets and UL-frames (Unknown unicast frames).

<b>Status</b>	Enable or disable the storm control feature for the port.
<b>Total Rate (Kbit/sec)</b>	Specify the upper rate limit for receiving the packets on the port. If the rate for receiving the packets on the port exceeds the total rate, the packets will be discarded.
<b>Included Storm Type</b>	<p>Select to filter broadcast/multicast/UL frame in the network. If the transmission rate of the chosen packets exceeds the total rate, the packets will be automatically discarded to avoid network broadcast storm. It is multi-optional.</p> <p><b>UL-Frame:</b> If UL-Frame packets traffic exceeds the rate on the port, they will be discarded.</p> <p><b>Multicast:</b> If multicast packets traffic exceeds the rate on the port, they will be discarded.</p> <p><b>Broadcast:</b> If broadcast packets traffic exceeds the rate on the port, they will be discarded.</p>

- 2) Click **Apply**.

---

 **Note:**


- For a port, the storm control feature and the ingress rate control feature cannot be enabled at the same time. If you enable storm control for a port, ingress rate control will be disabled for that port automatically.
  - For ports in the same LAG, storm control should be configured the same to ensure a successful port aggregation.
-

# 5 Configuration Example for Basic QoS

## 5.1 Network Requirements

As shown below, both RD department and Marketing department can access the internet. When congestion occurs, the traffic from two departments can both be forwarded and the traffic from the Marketing department should take precedence.

Figure 5-1 Basic QoS Application Topology



## 5.2 Configuration Scheme

To implement this requirement, you can configure QoS in port based mode to put the packets from the Marketing department into the queue with the higher priority than the packets from the RD department. Follow these procedures to configure QoS in port based mode.

- 1) Enable port based mode.
- 2) Map port 1 and port 2 to different priorities queues.

Demonstrated with TL-SG105E, the following section provides configuration steps.

### 5.3 Configuration Steps

- 1) Choose the menu **QoS > QoS Basic** to load the following page. In the **Global Config** section, select QoS mode as **Port Based**. Click **Apply**.

Figure 5-2 Configuring Basic QoS in Port Based Mode

**Global Config**

QoS Mode:  Port Based  802.1P Based  DSCP/802.1P Based

---

**Port-based Priority Setting**

Select	Port	Priority Queue
<input type="checkbox"/>		1(Lowest) ▾
<input type="checkbox"/>	Port 1	1(Lowest)
<input type="checkbox"/>	Port 2	1(Lowest)
<input type="checkbox"/>	Port 3	1(Lowest)
<input type="checkbox"/>	Port 4	1(Lowest)
<input type="checkbox"/>	Port 5	1(Lowest)

- 2) In the **Port Based Priority Setting** section, specify the priority queue for port 1 as **1(Lowest)** and click **Apply**. Specify the priority queue for port 2 as **4(Highest)** and click **Apply**.

Figure 5-3 Setting Different Priorities for Port 1 and Port 2

**Global Config**

QoS Mode:  Port Based  802.1P Based  DSCP/802.1P Based

---

**Port-based Priority Setting**

Select	Port	Priority Queue
<input type="checkbox"/>		4(Highest) ▾
<input type="checkbox"/>	Port 1	1(Lowest)
<input checked="" type="checkbox"/>	Port 2	4(Highest)
<input type="checkbox"/>	Port 3	1(Lowest)
<input type="checkbox"/>	Port 4	1(Lowest)
<input type="checkbox"/>	Port 5	1(Lowest)



# 6 Appendix: Default Parameters

Default settings of QoS basic configuration are listed in the following table.

Table 6-1 Default Settings of QoS Basic Configuration

Parameter	Default Setting
QoS Mode	DSCP/802.1P Based
Priority Queue	1 (Lowest)

Default settings of Bandwidth Control configuration are listed in the following table.

Table 6-2 Default Settings of Bandwidth Control Configuration


Parameter	Default Setting
Ingress Rate (Kbps)	Unlimited
Egress Rate (Kbps)	Unlimited

Default settings of Storm Control configuration are listed in the following table.

Table 6-3 Default Settings of Storm Control Configuration

Parameter	Default Setting
Status	Disable
Total Rate (Kbit/sec)	Unlimited

## COPYRIGHT & TRADEMARKS

Specifications are subject to change without notice.  tp-link is a registered trademark of TP-Link Technologies Co., Ltd. Other brands and product names are trademarks or registered trademarks of their respective holders.

No part of the specifications may be reproduced in any form or by any means or used to make any derivative such as translation, transformation, or adaptation without permission from TP-Link Technologies Co., Ltd. Copyright © 2018 TP-Link Technologies Co., Ltd. All rights reserved.

<http://www.tp-link.com>

## FCC compliance information statement



**Product Name:** 5/8/16-Port Gigabit Unmanaged Pro Switch

**Model Number:** TL-SG105E/TL-SG108E/TL-SG116E

Component Name	Model
I.T.E POWER SUPPLY	T090060-2B1(For TL-SG105E/TL-SG108E). T120100-2B1(For TL-SG116E)

**Responsible party:**

**TP-Link USA Corporation, d/b/a TP-Link North America, Inc.**

Address: 145 South State College Blvd. Suite 400, Brea, CA 92821

Website: <http://www.tp-link.com/us/>

Tel: +1 626 333 0234

Fax: +1 909 527 6803

E-mail: [sales.usa@tp-link.com](mailto:sales.usa@tp-link.com)

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference.
- 2) This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

For TL-SG105E/TL-SG108E

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee

that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

For TL-SG116E

This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

We, TP-Link USA Corporation, has determined that the equipment shown as above has been shown to comply with the applicable technical standards, FCC part 15. There is no unauthorized change is made in the equipment and the equipment is properly maintained and operated.

Issue Date: 2018-02-05

## FCC compliance information statement



**Product Name: I.T.E POWER SUPPLY**

**Model Number: T090060-2B1/T120100-2B1**

**Responsible party:**

**TP-Link USA Corporation, d/b/a TP-Link North America, Inc.**

Address: 145 South State College Blvd. Suite 400, Brea, CA 92821

Website: <http://www.tp-link.com/us/>

Tel: +1 626 333 0234

Fax: +1 909 527 6803

E-mail: [sales.usa@tp-link.com](mailto:sales.usa@tp-link.com)

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful

interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/ TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1) This device may not cause harmful interference.
- 2) This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

We, TP-Link USA Corporation, has determined that the equipment shown as above has been shown to comply with the applicable technical standards, FCC part 15. There is no unauthorized change is made in the equipment and the equipment is properly maintained and operated.

Issue Date: 2018-02-05

### **CE Mark Warning (For TL-SG105E/TL-SG108E)**



This is a class B product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

### **CE Mark Warning (For TL-SG116E)**



This is a class A product. In a domestic environment, this product may cause radio interference, in which case the user may be required to take adequate measures.

## EU declaration of conformity

TP-Link hereby declares that the device is in compliance with the essential requirements and other relevant provisions of directives 2014/53/EU, 2009/125/EC and 2011/65/EU.

The original EU declaration of conformity may be found at <http://www.tp-link.com/en/ce>

## Industry Canada Statement (For TL-SG105E/TL-SG108E)

CAN ICES-3 (B)/NMB-3(B)

## Industry Canada Statement (For TL-SG116E)

CAN ICES-3 (A)/NMB-3(A)

## BSMI Notice

安全諮詢及注意事項

- 請使用原裝電源供應器或只能按照本產品注明的電源類型使用本產品。
- 清潔本產品之前請先拔掉電源線。請勿使用液體、噴霧清潔劑或濕布進行清潔。
- 注意防潮，請勿將水或其他液體潑灑到本產品上。
- 插槽與開口供通風使用，以確保本產品的操作可靠並防止過熱，請勿堵塞或覆蓋開口。
- 請勿將本產品置放於靠近熱源的地方。除非有正常的通風，否則不可放在密閉位置中。
- 請不要私自打開機殼，不要嘗試自行維修本產品，請由授權的專業人士進行此項工作。

此為甲類資訊技術設備，于居住環境中使用時，可能會造成射頻擾動，在此種情況下，使用者會被要求採取某些適當的對策。(For TL-SG16E)

## 限用物質含有情況標示聲明書

產品元件名稱	限用物質及其化學符號					
	鉛 Pb	鎘 Cd	汞 Hg	六價鉻 CrVI	多溴聯苯 PBB	多溴二苯醚 PBDE
PCB	○	○	○	○	○	○
外殼	○	○	○	○	○	○
電源適配器	—	○	○	○	○	○

備考 1. “超出 0.1 wt %” 及 “超出 0.01 wt %” 系指限用物質之百分比含量超出百分比含量基準值。

備考 2. “○” 系指該項限用物質之百分比含量未超出百分比含量基準值。


備考 3. “—” 系指該項限用物質為排除項目。



Продукт сертифіковано згідно с правилами системи УкрСЕПРО на відповідність вимогам нормативних документів та вимогам, що передбачені чинними законодавчими актами України.





## Safety Information

- Keep the device away from water, fire, humidity or hot environments.
- Do not attempt to disassemble, repair, or modify the device.
- Do not use damaged charger or USB cable to charge the device.
- Do not use any other chargers than those recommended.
- Adapter shall be installed near the equipment and shall be easily accessible.
-  Use only power supplies which are provided by manufacturer and in the original packing of this product. If you have any questions, please don't hesitate to contact us.

Please read and follow the above safety information when operating the device. We cannot guarantee that no accidents or damage will occur due to improper use of the device. Please use this product with care and operate at your own risk.

## Explanation of the symbols on the product label

Symbol	Explanation
	AC voltage
	Indoor use only



## RECYCLING

This product bears the selective sorting symbol for Waste electrical and electronic equipment (WEEE). This means that this product must be handled pursuant to European directive 2012/19/EU in order to be recycled or dismantled to minimize its impact on the environment.

User has the choice to give his product to a competent recycling organization or to the retailer when he buys a new electrical or electronic equipment.

---

この装置は、クラスA情報技術装置です。この装置を家庭環境で使用すると電波妨害を引き起こすことがあります。この場合には使用者が適切な対策を講ずるよう要求されることがあります。

VCCI-A