




by Schneider Electric

Broadband PowerShield®

CP27U Models

User Manual



Chapter 1: General Information

The PowerShield® provides a power source for broadband telephony, Fiber-to-the-Home/Premise (FTTH/P), and other direct current (DC) equipment/applications.

Safety

This manual contains important instructions that should be followed during installation and maintenance of the APC equipment and batteries. It is intended for APC customers that set up, install, relocate, or maintain APC equipment.

Changes and modifications to this unit not expressly approved by APC could void the warranty. Failure to observe this warning may result in serious injury, death, or damage to the equipment.

Electrical Warnings

Do not work alone under hazardous conditions.

Servicing the PowerShield may require the removal of protective covers, as well as connected utility power. Use extreme caution during these procedures.

Check that the power cord(s), plug(s), and sockets are in good condition.

Replacement of fuses or other parts must be with identical types and ratings. Substitution of nonidentical parts may cause safety and fire hazards.

Battery Warning

Danger of explosion if the battery is incorrectly connected or replaced. Use only APC replacement batteries.

Unpacking

Inspect the unit upon receipt. Notify the shipping carrier or product supplier if there is damage.

The packaging is recyclable; save it for reuse or dispose of it properly.

Check the package contents. The package contains the enclosure, the battery (to be installed), one power cord, and the product documentation.

Specifications

General

Model Number	Input	Output	Maximum Signal Voltage	Maximum Signal Current	Battery Type
CP27U13	100-240 V 50/60 Hz 1.0 A	27 W 13 VDC 12VDC nominal	30 V	5 mA	12 V, 7.2 AHr Spill-Proof, Maintenance Free, Sealed Lead Acid

Environmental


Operating Temperature	-4° F to 122° F (-20° C to 50° C)
Operating Humidity	5 to 95% noncondensing within enclosure
Maximum Operating Elevation	10,000 ft (3,000 m)
Maximum Storage Elevation	50,000 ft (15,000 m)
Storage Temperature	-4° F to 122° F (-20° C to 50° C) Battery lifetime is reduced with prolonged storage in high temperatures (>25° C).

Physical

Height x Width x Depth	
PowerShield	7.5 x 9.5 x 3 in (19 x 24 x 7.6 cm)
PowerShield carton	13.5 x 13.5 x 4.5 in (34 x 34 x 11 cm)
Weight	
PowerShield	7.15 lbs (3.25 kg)
PowerShield with package materials	9 lbs (4 kg)

Chapter 2: Installation


Enclosure Installation




Install the PowerShield in a protected area that is free of excessive dust and has adequate airflow.

Do not operate the PowerShield where the temperature and humidity are outside the specified limits. See *Specifications*.


1



2




3




4

Use screws that are appropriate for the weight of this unit and the mounting surface material. See *Specifications*.




Battery Installation

1




2




Battery Cover Release Tabs


3



4




5



Connect Equipment and Power

The PowerShield battery charges when it is connected to utility power. The battery charges fully during the first eight hours of normal operation. **Do not** expect full battery run capability during this initial charge period.



1. Connect the PowerShield to the application equipment (example: FTTH/P Optical Network Terminal) via the seven-pin output connector, using the appropriate cable (must be ordered separately). See www.apc.com for a list of available output cables.
2. Plug the PowerShield power cord into the utility power cord inlet and then into the wall outlet.

Do not overload the wall outlet or circuit.

Cold Start Feature: Upon installation of a charged battery, power will immediately be applied to the unit even when utility power is not present.

Attention: To disconnect from utility power, remove the plug from the wall outlet.


Optional Runtime Extension




The runtime may be extended by adding the external battery CP20B12BP.

Chapter 3: Operation

Status Indicators and Features

Front Panel



Indicator	Description
Utility 	Solid green indicates the unit is on utility power. Solid yellow indicates that utility power is not present and the unit is on battery power. Flashing green LED indicates the unit is fast charging.
Output 	Green indicates the unit is working properly and DC output power is provided by the battery or the utility power.
Replace Battery/ Alarm Silence 	Red indicates that the battery must be replaced or that the battery is disconnected. See <i>Battery Replacement</i> . Pressing this button will silence the audible alarm. See <i>Alarm Silence Button</i> .


Automatic Self-Test

The unit automatically performs a self-test 31 hours after initial installation. Following this, a battery self-test will occur every 30 days. See *Alarm Silence Button* for manual self-test information.

Audible Alarm

Explanation	Description
On Battery	Four beeps in four seconds will be emitted one time only. This alarm will sound when the utility power is lost and the unit goes on battery power.
Low Battery Voltage	Every five minutes, four beeps in four seconds will be emitted. This alarm will sound when operating on battery and the battery voltage has dropped below threshold, indicating that less than 20% of available runtime remains.
Replace Battery	Every fifteen minutes, there will be a quarter-second beep when the battery fails the automatic self-test.

Alarm Silence Button

The audible alarms may be silenced by utilizing the dual function Replace Battery/Alarm Silence LED/button .






Function	Button Operation (Press and hold for:)	Description
Replace Battery Temporarily Enable/Disable	<4 seconds	If the alarm has been silenced, the unit will emit one quick beep. If the alarm has been enabled, two quick beeps will be emitted.
Replace Battery Permanently Enable/Disable	8-12 seconds	If the alarm has been silenced, the unit will emit one quick beep. If the alarm has been enabled, two quick beeps will be emitted.
Battery Self-Test Enable/Disable	4-8 seconds	If the self-test has been enabled, three beeps will be emitted. If the self-test cannot be enabled, a single beep will be emitted.* If the battery self-test has been canceled, the unit will emit four beeps.

*A battery self-test cannot be enabled unless the following conditions have been met.

1. Battery has been charged for at least 31 hours.
2. The unit has been on utility power for more than 12 hours.
3. Temperature is between 0 and 50°C.

Output Power and Communication Signals

The PowerShield communication signals are isolated from its internal circuitry via by open collector opto-coupled transistors. The connection labeled “Signal Return” is a common return point for all communication signals. In the typical application, the attached equipment digital ground connects to Signal Return, and pull-up resistors turn the open collector signals into logic levels.

—Vo +	+Voltage output
—Vo -	□ Voltage output
—SIG RTN 	Signal return.
—ON BATT 	Low when operating from utility line. Open when operating from battery.
—REPLACE BATT 	Low when battery is charged. Open when battery fails the Self-Test.
—BATT MISSING 	Low when battery is present. Open when battery is missing.
—LOW BATT 	Low when battery is near full charge capacity. Open when operating from a battery with less than 20% of available runtime remaining.

Chapter 4: Maintenance, Service, Contact Information, and Warranty

Battery Replacement

This unit has an easy to replace battery. Battery replacement can be performed while the unit and connected equipment are operating.

During a self-test, battery removal and replacement are not recommended. For self-test disabling, see *Alarm Silence Button*.

Replace the used battery with APC replacement battery RBC2. See your dealer or refer to the APC Web site, www.apc.com, for information on replacement batteries.

For battery replacement, see *Battery Installation*.



Once the battery is disconnected, the connected equipment is not protected from power outages.



Be sure to deliver used batteries to a recycling facility found on the *Used Battery Return Facilities* list included with RBC2.

Service

If the unit requires service, do not return it to the dealer. Follow these steps:

1. Contact APC Customer Support through the APC web site at www.apc.com.
 - a) Note the product model number, the serial number, and the date of purchase.
 - b) Call APC Customer Support and a technician will attempt to solve it over the phone. If this is not possible, the technician will issue a Returned Material Authorization Number (RMA#).
 - c) If the product is under warranty, repairs are free. If not, there is a repair charge.
 - d) Service procedures and returns may vary internationally. Refer to the APC web site for country specific instructions.
2. Pack the unit properly to avoid damage in transit. Never use Styrofoam beads for packaging. Damage sustained in transit is not covered under warranty.
3. Before shipping, always disconnect all battery modules.
4. Write the RMA# provided by Customer Support on the outside of the package.
5. Return the unit by insured, prepaid carrier to the address provided by Customer Support.

Limited Factory Warranty

Schneider Electric IT Corporation (SEIT), warrants its products to be free from defects in materials and workmanship for a period of two (2) years from the date of purchase. The SEIT obligation under this warranty is limited to repairing or replacing, at its sole discretion, any such defective products. Repair or replacement of a defective product or parts thereof does not extend the original warranty period.

This warranty applies only to the original purchaser who must have properly registered the product within 10 days of purchase. Products may be registered online at warranty.apc.com.

SEIT shall not be liable under the warranty if its testing and examination disclose that the alleged defect in the product does not exist or was caused by end user or any third person misuse, negligence, improper installation, testing, operation or use of the product contrary to SEIT recommendations or specifications. Further, SEIT shall not be liable for defects resulting from: 1) unauthorized attempts to repair or modify the product, 2) incorrect or inadequate electrical voltage or connection, 3) inappropriate on site operation conditions, 4) Acts of God, 5) exposure to the elements, or 6) theft. In no event shall SEIT have any liability under this warranty for any product where the serial number has been altered, defaced, or removed.

EXCEPT AS SET FORTH ABOVE, THERE ARE NO WARRANTIES, EXPRESS OR IMPLIED, BY OPERATION OF LAW OR OTHERWISE, APPLICABLE TO PRODUCTS SOLD, SERVICED OR FURNISHED UNDER THIS AGREEMENT OR IN CONNECTION HEREWITH.

SEIT DISCLAIMS ALL IMPLIED WARRANTIES OF MERCHANTABILITY, SATISFACTION AND FITNESS FOR A PARTICULAR PURPOSE.

SEIT EXPRESS WARRANTIES WILL NOT BE ENLARGED, DIMINISHED, OR AFFECTED BY AND NO OBLIGATION OR LIABILITY WILL ARISE OUT OF, SEIT RENDERING OF TECHNICAL OR OTHER ADVICE OR SERVICE IN CONNECTION WITH THE PRODUCTS.

THE FOREGOING WARRANTIES AND REMEDIES ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES AND REMEDIES. THE WARRANTIES SET FORTH ABOVE CONSTITUTE SEIT SOLE LIABILITY AND PURCHASER EXCLUSIVE REMEDY FOR ANY BREACH OF SUCH WARRANTIES. SEIT WARRANTIES EXTEND ONLY TO ORIGINAL PURCHASER AND ARE NOT EXTENDED TO ANY THIRD PARTIES.

IN NO EVENT SHALL SEIT, ITS OFFICERS, DIRECTORS, AFFILIATES OR EMPLOYEES BE LIABLE FOR ANY FORM OF INDIRECT, SPECIAL, CONSEQUENTIAL OR PUNITIVE DAMAGES, ARISING OUT OF THE USE, SERVICE OR INSTALLATION OF THE PRODUCTS, WHETHER SUCH DAMAGES ARISE IN CONTRACT OR TORT, IRRESPECTIVE OF FAULT, NEGLIGENCE OR STRICT LIABILITY OR WHETHER SEIT HAS BEEN ADVISED IN ADVANCE OF THE POSSIBILITY OF SUCH DAMAGES. SPECIFICALLY, SEIT IS NOT LIABLE FOR ANY COSTS, SUCH AS LOST PROFITS OR REVENUE, WHETHER DIRECT OR INDIRECT, LOSS OF EQUIPMENT, LOSS OF USE OF EQUIPMENT, LOSS OF SOFTWARE, LOSS OF DATA, COSTS OF SUBSTITUANTS, CLAIMS BY THIRD PARTIES, OR OTHERWISE.

NOTHING IN THIS LIMITED WARRANTY SHALL SEEK TO EXCLUDE OR LIMIT SEIT LIABILITY FOR DEATH OR PERSONAL INJURY RESULTING FROM ITS NEGLIGENCE OR ITS FRAUDULENT MISREPRESENTATION OF TO THE EXTENT THAT IT CANNOT BE EXCLUDED OR LIMITED BY APPLICABLE LAW.

To obtain service under warranty you must obtain a Returned Material Authorization (RMA) number from customer support. Customers with warranty claims issues may access the SEIT worldwide customer support network through the APC web site: www.apc.com. Select your country from the country selection drop down menu. Open the Support tab at the top of the web page to obtain information for customer support in your region. Products must be returned with transportation charges prepaid and must be accompanied by a brief description of the problem encountered and proof of date and place of purchase.

APC™ by Schneider Electric Worldwide Customer Support

Customer support for this or any other APC™ by Schneider Electric product is available at no charge in any of the following ways:

- Visit the APC by Schneider Electric web site, www.apc.com to access documents in the APC Knowledge Base and to submit customer support requests.
 - www.apc.com (Corporate Headquarters)
Connect to localized APC by Schneider Electric web site for specific countries, each of which provides customer support information.
 - www.apc.com/support/
Global support searching APC Knowledge Base and using e-support.
- Contact the APC by Schneider Electric Customer Support Center by telephone or e-mail.
 - Local, country specific centers: go to www.apc.com/support/contact for contact information.
 - For information on how to obtain local customer support, contact the APC by Schneider Electric representative or other distributor from whom you purchased your APC by Schneider Electric product.

© 2016 APC by Schneider Electric. APC, the APC logo are owned by Schneider Electric Industries S.A.S. or their affiliated companies. All other trademarks are property of their respective owners.