

Item Number
RAM-VB-131R4

RAM No-Drill™ Seat Bases

RAM Mounting Systems

Vehicle base for the

GMC SIERRA (DELUXE POWER SEATS)
(2000-2006)

GMC YUKON (DELUXE POWER SEATS)
(2000-2006)

CHEVY SILVERADO (DELUXE POWER SEATS)
(1999-2006)

CHEVY SUBURBAN (DELUXE POWER SEATS)
(2000-2006)

CHEVROLET 2500 & 3500 C/K SERIES TRUCK (DELUXE POWER SEATS) (2000-2006)

CHEVROLET AVALANCHE (2000-2006)

HUMMER H2 (2005-2006)

CADILLAC ESCALADE (2000-2006)

SPECIFICATIONS

Placement

Passenger side, in front, where seat frame meets floor board.

Drilling Required

None - uses existing seat bolts

Seat Configuration

Bucket

Construction/Finish

Steel/Black Powdercoat

Pole or Pedestal

Ordered Separately

Riser

Included

Weight 7.7 lbs.

Dimensions

Hole Center = 15"

Features

Installs in minutes with no drilling required
Won't interfere with levers, factory-installed console, or 4WD lever

Misc.

Rock solid construction
Lifetime warranty

RAM Mounting Systems

8410 Dallas Ave S
Seattle, WA 98108
Phone: (206) 763-8361
Fax: (206) 763-9615
www.rammount.com
support@rammount.com



Shown In Use



RAM-VB-131R4



RMR-INS-VB-131R4

Item Number
RAM-VB-131R4

RAM No-Drill™ Seat Bases

RAM Mounting Systems

Vehicle base for the

GMC SIERRA (DELUXE POWER SEATS)
(2000-2006)

GMC YUKON (DELUXE POWER SEATS)
(2000-2006)

CHEVY SILVERADO (DELUXE POWER SEATS)
(1999-2006)

CHEVY SUBURBAN (DELUXE POWER SEATS)
(2000-2006)

CHEVROLET 2500 & 3500 C/K SERIES TRUCK (DELUXE POWER SEATS) (2000-2006)

CHEVROLET AVALANCHE (2000-2006)

HUMMER H2 (2005-2006)

CADILLAC ESCALADE (2000-2006)

INSTALLATION INSTRUCTIONS

Note that attaching the riser prior to installing the base into the vehicle is suggested.

Tools needed for installation are 9/16" deep socket and 1/2" box end wrench for attachment a riser if being used.

1. Move the passenger side seat to its rear most position.
2. Locate the two front seat frame nuts holding the passenger side seat to the floor board. The one closest to the passenger side door may be located within the seat track. The nut closest to the center of the vehicle may be under a piece of plastic trim but is located outside of the seat track toward the inside of the seat frame. Both have a star shape nut and can be loosened using a 9/16" deep socket and socket wrench.
3. Loosen the two nuts holding the front of the passenger side seat to the floor board. Only loosen enough to pass the no drill base in between the seat tracks and floor board.
4. Once there is enough room for the base, slide the base under the seat so that the notches align with the seat studs projecting upward from the floor board. Make sure the back of each slots engage the seat studs.
5. Using the 9/16" socket and socket wrench, fully tighten the seat frame nuts to secure the base in place.

RAM Mounting Systems
8410 Dallas Ave S
Seattle, WA 98108
Phone: (206) 763-8361
Fax: (206) 763-9615
www.rammount.com
support@rammount.com



RMR-INS-VB-131R4