

Item Number
RAM-VB-150

RAM No-Drill™ Seat Bases

RAM Mounting Systems

**Vehicle base for the
SCION xB (2005-2007)**

SPECIFICATIONS

Placement

Passenger side on the floor, under front seat

Drilling Required

No - uses existing seat bolts

Pole or Pedestal

Sold Separately

Seat Configuration

Bucket

Weight 4.8 lbs.

Construction/Finish

Steel/Black Powdercoat

Dimensions

Length = 18.125", Depth = 9.625"

Height = 2.25", Hole Centers = 16.625"

Features

Installs in minutes with no drilling required

Low profile keeps mount away from passenger leg space

Misc.

Rock solid construction

Lifetime warranty



Shown In Use



RAM-VB-150

RAM Mounting Systems

8410 Dallas Ave S
Seattle, WA 98108
Phone: (206) 763-8361
Fax: (206) 763-9615
www.rammount.com
support@rammount.com



RMR-INS-VB-150

Item Number
RAM-VB-150

RAM No-Drill™ Seat Bases

RAM Mounting Systems

**Vehicle base for the
SCION xB (2005-2007)**

INSTALLATION INSTRUCTIONS

1. Move the passenger seat back to its rearmost position and remove the front seat rail bolts. Store these bolts.
2. Without moving the seat, place the No-Drill™ base over the front of the seat frame legs.
3. Align the holes in the base with those of the seat frame legs. The pedestal platform should be near the console.
4. Using the supplied longer seat bolts and washers, secure the no drill base over the seat frame legs.
5. Fully tighten the seat leg bolts. It is suggested to start these bolts by hand to avoid cross threading.

RAM Mounting Systems
8410 Dallas Ave S
Seattle, WA 98108
Phone: (206) 763-8361
Fax: (206) 763-9615
www.rammount.com
support@rammount.com



RMR-INS-VB-150