

URBAN-X Pro - 'Quick Start'



Important Safety Information -
See Full Instructions



Eye Safety



High Voltage

The URBAN-X Pro is delivered in two parts; (a) the main body of the luminaire, and (b) the pole mount arm. These two parts must be assembled prior to installation.

Instructions (For cable fitted models, go to point 7)

1. Open lid (2 screws).
2. Prepare the mains supply cable. See cable preparation diagram below. Feed cable through gland and into the unit.
3. Terminate mains supply wires to terminal block.
4. Tighten the cable gland nut so the cable is held securely and the environmental seal is maintained.
5. Tighten cable to base plate using cable tie from accessories bag. Clip out excess cable tie tail.
6. Close and secure lid using screws provided. Tighten to 4Nm (make sure no wires are trapped by the lid).
7. Feed supply cable through the pole mount arm before securing it to the luminaire.
8. Align pole mount arm to the back of the luminaire in the orientation required and secure using screws and washers provided. Tighten to 17NM (the spring washer is located between the M8 washer and the head of the M8 screw).
9. Mount unit on an appropriately sized pole (60-76mm Diameter) and secure with supplied grub screws. Tighten to 17Nm.

Optional DALI – wires should be stripped to 8.5mm-9.5mm and suitably terminated. Connect to the driver terminals labelled DA(BL) Blue.

Cable preparation diagram:

