


# **AXIS T94M02L Recessed Mount**

## **Installation Guide**



# AXIS T94M02L Recessed Mount




4x




4x




4x




1x



1x





1x






1x




# AXIS T94M02L Recessed Mount



1




# AXIS T94M02L Recessed Mount




# AXIS T94M02L Recessed Mount

---

2





3



4

i


AXIS Q35-VE/-LVE	L=150 mm (6 in)
AXIS P32-VE/-LVE	L=150 - 250 mm (6 - 10 in)
AXIS P33-VE	L=150 mm (6 in)




# AXIS T94M02L Recessed Mount

---


5





6








7




# AXIS T94M02L Recessed Mount



8




9




10




# AXIS T94M02L Recessed Mount





11




12




13





# AXIS T94M02L Recessed Mount




14





15







16



4x

T20


17




# AXIS T94M02L Recessed Mount

---

18









1



4x



AXIS Q35-LVE




4x




# AXIS T94M02L Recessed Mount


2




3



4




5




# AXIS T94M02L Recessed Mount


6




7



8





9




# AXIS T94M02L Recessed Mount

---

10



AXIS P32-VE/-LVE




1


4x



TR20




AXIS P3214-VE  
AXIS P3215-VE



4x




TR20




# AXIS T94M02L Recessed Mount




2



3









# AXIS T94M02L Recessed Mount


7




8



9





10




# AXIS T94M02L Recessed Mount


---

11







1




# AXIS T94M02L Recessed Mount


2





4x




3



4




5




# AXIS T94M02L Recessed Mount


6



7




8






9





10




# AXIS T94M02L Recessed Mount

---

11





# AXIS T94M02L Recessed Mount




1


2x



2



3



Installation Guide

AXIS T94M02L Recessed Mount

© Axis Communications AB, 2015 - 2017

Ver. M4.2

Date: July 2017

Part No. 1751552