Intelliskin™ with GDS™ Technology - User Guide

For a video demonstration of your specific IntelliSkin™, visit www.rammount.com and search for the Product ID of your IntelliSkin™.

*Recommended: Attach or remove IntelliSkin™ when at room temperature.

To Attach IntelliSkin™:

1. Locate Inside Charging Connector of your IntelliSkin™. Align your device with IntelliSkin™ with Power Port on same side as Inside Charging Connector.





2. Insert bottom corners of your device into the center of IntelliSkin™ lengthwise, wrapping edges of IntelliSkin™ in front of the device.

If your device is having a difficult time sliding into the IntelliSkin™, apply a small amount of lubricant to the side edges of your tablet.



3. Caution: Carefully connect **Inside Charging Connector** to your device in a straight and even motion. Once the charging connector is fully engaged, continue to wrap and stretch remaining IntelliSkin™ edges over your device.





Once attached, test IntelliSkin™ with device on any GDS™ Dock. When dock is plugged in, IntelliSkin™ should relay power to your device within two seconds.

To Remove IntelliSkin™:

1. Locate Inside Charging Connector of IntelliSkin™, which will be located inside the Visible Protrusion of the IntelliSkin™. If your IntelliSkin™ has No Protrusion, it will be located in the same place as the outside docking contacts.

Visible Protrusion: Charging Connector located here





Slowly peel

from this corner

2. On the opposite side of the Inside Charging Connector, select the corner closest to the device's buttons and other ports. Starting with this corner, slowly peel the IntelliSkin™ away from your device.







3. Continue peeling towards the closest adjacent corner. Once

two corners are fully exposed, slide your device straight away

from the Inside Charging Connector from the opposite side.





RPR-INS-GDS-SKIN-7

Warranty Information

3 Year Warranty on all IntelliSkin™ products

The exclusive NPI Warranty states that all IntelliSkin™ products are warranted against defect in materials and workmanship for three years from the date of purchase of the product or part. NPI Warranty covers the product or its components only. The device alone is not covered and will not be replaced if damaged as a result of product failure. This warranty is expressly limited to persons in the United States, and all foreign countries who purchase IntelliSkin™ for resale or use in the ordinary course of the buyer's business. This warranty does not cover any product or part that has been abused, worn out, heated, ground or otherwise altered, used for a purpose other than that for which it was intended, or used in a manner inconsistent with any instructions regarding its use.

Get the most out of your IntelliSkin™ with GDS™ Technology

All GDS[™] docks and accessories are compatible with any IntelliSkin[™] product, whether you are supporting your phone, small tablet or large tablet.



Visit <u>www.gdstech.com</u> for alternate docks or IntelliSkin[™] for any tablet or phone.

National Products Inc. 8410 Dallas Ave S Seattle WA 98108 Phone: (206) 763-8361 Fax: (206) 763-9615 www.rammount.com support@rammount.com



GDS™, IntelliSkin™, GDS Tech™, GDS Technology™ and GDS Compatible™ are trademarks or registered trademarks of National Products Inc. The distinctive D Shape™ of the GDS™ connector is a trademark of National Products Inc.

PATENTS AND TRADEMARKS WWW.RAMMOUNT.COM/IP



RPR-INS-GDS-SKIN-7