

Item Number
RAM-VB-138ST2

RAM No-Drill™ Seat Bases

RAM Mounting Systems

**Vehicle base for the
TOYOTA HIGHLANDER (2008-2010)**

SPECIFICATIONS

Placement

Passenger side on the floor, under front seat

Drilling Required

No - uses existing seat bolts

Seat Configuration

Bucket

Construction/Finish

Steel/Black Powdercoat

Pole or Pedestal

Sold Separately

DimensionsA = 17.125",
B = 6.5", C = 5"
Hole Center = 15.875"

Weight 7.0 lbs.




Shown In Use

Features

Installs in minutes with no drilling required
Low profile keeps mount away from passenger leg space

Misc.

Rock solid construction
Lifetime warranty



RAM-VB-138ST2

RAM Mounting Systems
8410 Dallas Ave S
Seattle, WA 98108
Phone: (206) 763-8361
Fax: (206) 763-9615
www.rammount.com
support@rammount.com



RMR-INS-VB-138ST2

Item Number
RAM-VB-138ST2

RAM No-Drill™ Seat Bases

RAM Mounting Systems

**Vehicle base for the
TOYOTA HIGHLANDER (2008-2010)**

INSTALLATION INSTRUCTIONS

1. Attaching the fixed riser to the No-Drill™ base should be done prior to attaching the base to the vehicle. For a finished look, assemble so the rounded heads of the carriage bolts are on top.
2. Move the passenger seat back to its rearmost position and remove the front seat rail bolts using a 14mm socket wrench. Save and store these bolts should the mount be later removed.
3. Using the provided hardware, place the washers over the longer bolts, pass the bolts through the No-Drill™ base, next through the round stand-offs, and align over the threaded holes in the floor board.
4. Start bolts by hand to insure that the bolts do not cross thread
5. Using a 17mm socket wrench, fully tighten the bolts to secure the base.
6. After a day of use, re-tighten the seat bolts holding the mount.



RAM Mounting Systems
8410 Dallas Ave S
Seattle, WA 98108
Phone: (206) 763-8361
Fax: (206) 763-9615
www.rammount.com
support@rammount.com



RMR-INS-VB-138ST2